



AMERICAN ATHLETIC, INC  
200 AMERICAN AVE.  
JEFFERSON, IOWA 50129  
PHONE 515-386-3125



**FEM 42 BLUE CARPET**  
**FEM 45 BLUE CARPET**

<b>MODEL NUMBER</b> 432505/432500/ 432504/432545	<b>LAST REVISION DATE</b> 11-25-08	<b>INSTRUCTION NO.</b> 81505
--	---------------------------------------	---------------------------------

ASSEMBLY PARTS LIST FOR 432500 (42' FEM BLK SAPPHIRE CARPET)

KEY	PART NO	DESCRIPTION	QTY
1	0004175	4" BLACK VELCRO HOOK	45 YD
2	0005360	2" WHITE TAPE	1 ROLL
3	0432501	FEM 42 END CARPET	2
4	0432502	FEM 42 LARGE MIDDLE CARPET	1
5	0432503	FEM 42 SMALL MIDDLE CARPET	1

ASSEMBLY PARTS LIST FOR 432545 (42' FEM NEWPORT CARPET)

KEY	PART NO	DESCRIPTION	QTY
1	0004175	4" BLACK VELCRO HOOK	45 YD
2	0005360	2" WHITE TAPE	1 ROLL
3	0432531	FEM 42 END CARPET	2
4	0432532	FEM 42 LARGE MIDDLE CARPET	1
5	0432533	FEM 42 SMALL MIDDLE CARPET	1

ASSEMBLY PARTS LIST FOR 432505 (45' FEM BLK SAPPHIRE CARPET)

KEY	PART NO	DESCRIPTION	QTY
1	0004175	4" BLACK VELCRO HOOK	45 YD
2	0005360	2" WHITE TAPE	1 ROLL
3	0432506	FEM 45 END CARPET	2
4	0432507	FEM 45 MIDDLE CARPET	2

ASSEMBLY PARTS LIST FOR 432504 (45' FEM NEWPORT CARPET)

KEY	PART NO	DESCRIPTION	QTY
1	0004175	4" BLACK VELCRO HOOK	45 YD
2	0005360	2" WHITE TAPE	1 ROLL
3	0432534	FEM 45 END CARPET	2
4	0432535	FEM 45 MIDDLE CARPET	2

BEFORE YOU BEGIN ASSEMBLY

- ◆ YOUR FEM 42 BLUE CARPET COMES IN FIVE PACKAGES (432500 & 432545)
  - (2) FEM 42 END CARPET
  - (1) FEM 42 LARGE MIDDLE CARPET
  - (1) FEM 42 SMALL MIDDLE CARPET
  - (1) FEM ACCESSORY PACKAGE
  
- ◆ YOUR FEM 45 BLUE CARPET COMES IN FIVE PACKAGES (432505 & 432504)
  - (2) FEM 42 END CARPET
  - (2) FEM 42 MIDDLE CARPET
  - (1) FEM ACCESSORY PACKAGE

#### ASSEMBLY INSTRUCTIONS

1. LAY OUT THE FOAM ROLLS THAT YOU WILL BE USING UNDERNEATH YOUR CARPET.
  2. LAY THE CARPET SECTIONS ON TOP OF THE FOAM IN THE ARRANGEMENT SHOWN IN THE ILLUSTRATION (BE SURE TO LAY THE CARPET PERPENDICULAR TO THE FOAM SECTIONS). USE THE 4" VELCRO HOOK TO FASTEN THE CARPET SECTIONS TOGETHER ON THE SEAMS.
  3. ROLL OUT VELCRO STRAP NEAR THE EDGE OF THE CARPET. LIFT ONE EDGE OF A CARPET & TUCK HALF OF THE VELCRO STRAP UNDERNEATH (DOWN THE ENTIRE LENGTH OF CARPET). LIFT THE EDGE OF THE REMAINING CARPET UNTIL THE VELCRO FALLS UNDER THE CARPET. LAY THE CARPET BACK DOWN & SECURE IT TO THE VELCRO STRAP. ENSURE THIS IS DONE DOWN THE ENTIRE LENGTH OF THE CARPET. REPEAT PROCESS FOR THE REMAINING CARPETS.
  4. USE THE WHITE TAPE AROUND THE EDGE TO FORM THE BORDER FOR THE WORKING AREA OF YOUR FLOOR. USE THE DIMENSIONS SHOWN ON THE FIGURE BELOW. TAPE SHOULD BE EQUALLY SPACED FROM ALL OUTSIDE EDGES OF THE CARPET.
- ✓ NOTE: DIMENSIONS SHOWN ARE INSIDE OF TAPE TO INSIDE OF TAPE. THE DISTANCE FROM THE EDGE OF THE CARPET TO THE INSIDE OF THE TAPE SHOULD BE APPROXIMATELY 13-3/4" FOR THE 42' CARPET AND 31-3/4" FOR THE 45' CARPET.

#### USE OF THIS EQUIPMENT

1. THIS CARPET IS INTENDED FOR USE OVER A SPRING OR FOAM FLOOR DECK AND 1-3/8" TO 2" OF FOAM PADDING.
2. PERIODIC CLEANING OF YOUR CARPET AND CHECKING OF THE VELCRO ATTACHMENTS IS RECOMMENDED AND MAY INCREASE THE USEFUL LIFE OF YOUR EQUIPMENT.

