

AI Fong Spotting Blocks Assembly Instructions

1. After you have received your products, remove outer packaging and make sure both pieces of foam (Hard foam, and 4" thick EVA Crosslink) and matching cover for each block has arrived.
2. Place the 4" thick EVA crosslink foam with the plastic film side up.
3. Slowly peel off the plastic film starting from a corner. The plastic will peel off like a large sticker. For the larger blocks use two people starting on the same side at each corner.
4. Make sure to avoid touching or placing objects on the sticky side of the foam once the film is off.
5. Arrange the larger firmer foam so the dimensions will match the 4" foam top dimensions when placed on top.
6. Using two people one on each side, flip the top foam over so the sticky side is facing down and carefully line up the corners with the firmer bottom foam. Loosely set the 4" EVA foam on top of the bottom foam and make sure the corners and sides line up.
7. If the corners or sides aren't matched up it may be possible to lift the top foam a bit and adjust, if the foams haven't been firmly pressed together yet.
8. Once the foams are lined up correctly firmly press the 4" EVA top foam to the firmer bottom foam.
9. We found the easiest and smoothest way to insert the foam blocks in their covers is to turn the foam upside down (hard foam will be sitting on top of the softer EVA Crosslink Foam) and slide the cover over the foam.
10. Using two people place the coordinating block cover over the firm foam.
11. Make sure all four corners are covered first before beginning to work the cover down.
12. Little by little pull the cover down on each corner keeping them level.
13. Once the cover has been placed all the way on and there are no gaps or large wrinkles flip the block over.
14. Tightly pull the top of the cover over the 4" EVA Crosslink foam, tucking each corner in until the zipper meets together.
15. Have one person pull the zipper together to make it easier to zip. Corners may be a bit tougher to zip. You can push in on the 4" EVA Crosslink foam to make the corners easier.
16. Check to make sure there are no large gaps or wrinkles and the cover has a snug fit.